



**RPC Electronics, LLC**

# **RTrak-Lite**

**Integrated APRS Tracker**

## **User's Manual**



**Revision A**  
**Written By: Jason Rausch KE4NYV**  
**Copyright 2011 RPC Electronics, LLC**

# Table of Contents

- 1. Introduction and Acknowledgments**
- 2. Package Contents**
- 3. Device Overview and Specifications**
- 4. Connections**
- 5. Getting Started**
- 6. Basic APRS Programming**
  - **Callsign**
  - **Icon**
  - **APRS Path**
  - **Beacon Rate**
- 7. Major Component Specifications**
  - **OpenTracker 1+**
  - **MN5010HS GPS Chipset**

# **Introduction**

Thank you for purchasing an RTrak-Lite! We are pleased that you have decided to make it part of your amateur radio equipment and hope that it will serve you well for many years to come. Please take some time to read through this manual and familiarize yourself with the functions of your new RTrak-Lite and how to operate it properly.

# **Acknowledgments**

Special thanks to the following people for helping make the RTrak-Lite possible:

Scott Miller N1VG  
Shaena Hicks KI4UDD

# Package Contents

- Your new RTrak-Lite comes with everything required to get started, minus the radio, antenna and computer for initial programming.

## **Included Items:**

- RTrak-Lite APRS Tracker
- Active GPS Patch Antenna
- 12VDC Lighter Power Cable
- DB9 Serial to 2.5mm Stereo Programming Cable
- CD Containing this manual and specification sheets on key components

# Device Overview and Specifications

- The RTrak-Lite is the only model in the RTrak family that does NOT have an internal radio/transmitter. The RTrak-Lite requires the end user to interface it to any VHF/UHF FM radio of their choice. The main advantage to this is the ability to use a radio with any transmitting power level and have an internal receiver to check for channel activity before transmitting.

**OpenTracker 1+:** The data modem section of the RTrak-Lite is based on the SMT OpenTracker 1+ platform. The OpenTracker was designed and programmed by Scott Miller N1VG of Argent Data Systems. The OT1+ platform is fully open source and a perfect match for the RTrak-Lite tracker. Firmware upgrades are free for download.

**MN5010HS:** The GPS receiving chipset used in the RTrak-Lite. This GPS is a Sirf-Star III receiver with a fast <60 sec cold start lock time, measures only 10mm x 10mm in size and runs on a 5V operating voltage.



# Connections

- There are three main connections that will be used any time the RTrak-Lite is in full operating mode: Power, GPS Antenna and Radio.

## **Power**

The RTrak-Lite can be powered with any 9-20 VDC source. This makes it perfect for use in a vehicle, boat or just about any other mobile form of transportation. The power jack is a standard coaxial 2.1mm I.D. jack with a positive center (tip) polarity

The included lighter cable is perfect for most vehicle applications. In portable or human power applications, such as a bike or hiking, a battery pack may be used to power the tracker. A 12VDC gel cell or similar Lithium-Polymer style battery would be sufficient.

## **GPS**

The GPS connection is a standard polarity, SMA female RF connector suited to mate with the included GPS active patch antenna. Be sure to tighten antenna connector finger tight. DO NOT use a wrench to torque the connector tight. This is not needed and risks damage to the connector or main RTrak-Lite board.

## **Radio**

The radio interface is a standard RJ-45 ethernet style connector. All required signals to connect the tracking to any VHF/UHF FM radio are available at this connector. A interfacing cable with a pre-installed RJ-45 connector and bare wire ends is included with the tracker package. For a pinout, please see Appendix A.

## **Programming Port**


The programming port is a stereo 2.5 mm jack used only when the RTrak-Lite needs to be configured for operation. This is a self-isolating jack that is engaged only when the programming cable is inserted. Failure to remove this cable during normal operation will block GPS data from getting to the on-board OpenTracker. The cable must be removed to restore this internal connection.

## Rear Panel



# Getting Started

- Getting started is easy with the RTrak-Lite.
  1. Simply connect the included power cable and GPS antenna.
  2. Install the programming software included on the RTrak-Lite User's CD on any computer with a 9 pin serial port. Note: Some USB>Serial adapters have been reported to work with this software. Use at your own risk.
  3. Ensure that power to RTrak-Lite is REMOVED.
  4. Connect the programming cable to the RTrak-Lite's programming port and the computer's serial port.
  5. Plug power into the RTrak-Lite.
  6. Start up the RTrak programming software: rtrak-prog.exe. You will see a window like this:



7. Select the appropriate com port and click Connect.
  8. If the software properly reads the RTrak-Lite, the connect window will close and open up a configuration window containing all of the current settings.
- When you get to this point, proceed with the following page of Basic APRS Programming instructions.

# Basic APRS Programming

- **Callsign:** Use your FCC assigned Amateur Radio callsign for this field

Examples: KE4NYV KI4UDD N1VG

- **Callsign with SSID:** The use of an SSID can aid in the multiple use of a single callsign. The SSID ID will be designated by a dash (-) sign and a number of 1-15. These SSIDs typically have specific meaning, so check with your local APRS users for the SSID that is appropriate for a non-receiving APRS tracker.

Examples: KE4NYV-15 KI4UDD-12 N1VG-9

- **Icon:** The icon symbol will tell any receiving station what icon to use when displaying your position on an APRS map.

## Common APRS Icon Symbols

Car		/>
Truck		/k
Van		/v
18 Wheeler		/u
Bike		/b
Hiker		/[
Ambulance		/a
Jeep		/j
RV		/R
Airplane		/^
Boat		/Y

- **Path:** The path is used to route your packet as far as you would like it to go, within reason. You want to make your path fall into the guidelines of your local area and that is hard to determine through a manual. This manual will give you some common examples to start with.

Examples: WIDE1-1 WIDE2-2 WIDE1-1,WIDE2-2

- **Beacon Rates:** The RTrak-Lite is capable of two beacon schemes.
  1. **Static Beacon** – This method uses a pure timing scheme to beacon at a constant rate set in programming. This rate cannot be changed unless the configuration software and cable are used to make the change.

The static beacon rate is set in seconds, meaning 30 = 30 seconds, 60 = 1 minute and so on. A typical static beacon rate is 3-5 minutes.

2. **SmartBeaconing™** – This method uses the current GPS data to determine when to beacon and how often.

There are two main elements to the SmartBeaconing™ algorithm:

- **Speed-Adjusted Beacon Rate** – Depending on your travel speed, the beacon rate is either increased or decreased. When traveling faster, the tracker is covering more ground and beacons more often. When traveling slower or stopped, the beacon rate is less often since it is not moving far or may be sitting still.
  - **Cornerpegging** – While moving, the SB algorithm is constantly monitoring the heading of travel. When this degree of heading has changed past a certain threshold, it triggers a beacon to indicate either a long steady curve or a direct turn around a corner. The result is a much more defined track.
- After all settings have been made, the last step is to write the configuration back to the RTrak-Lite. Click the “Write” button located in the bottom right of the configuration window. When the software is completed loading the settings, you will be asked to click the “OK!” button. The software returns to the main configuration screen where it can be exited.
  - Power down the RTrak-Lite by removing power from the power jack. Remove the programming cable and power the unit back up for normal operation. You are now ready to put your RTrak-Lite into service.

**NOTE:** Any additional settings can be found in the OpenTracker manual, included on the RTrak-Lite User’s CD


# Major Component Specifications

- **OpenTracker 1+**
  - **Operating Voltage** DC 6.5-28V or 5VDC Regulated
  - **Operating Current** 8 mA Idle, 20 mA Transmitting
  - **Modes** 1200 bps AFSK
  - **GPS Interface** NMEA 4800 bps
  
- **MN5010HS**
  - **Receiver Class** Sirf-Star III
  - **Channel** 20
  - **Operating Voltage** 3.25-5.5 VDC
  - **Cold Start Lock Time** >30 Second
  - **Interface** NMEA-0183
  - **Sensitivity** -145dBm at Acquisition
  - **Maximum Altitude** 60K Feet
  - **Operating Current** 30 mA

## Appendix A

- Radio Port Pinout

<b>PIN</b>	<b>FUNCTION</b>	<b>COLOR</b>
1	TX Audio	Orange/White
2	IRQ	Orange
3	PTT	Green/White
4	ADC 1	Blue
5	RX Audio	Blue/White
6	Ground	Green
7	+V Input	Brown/White
8	1WIRE	Brown



- When using the supplied interface cable, the color code in the above table will be valid. If using an aftermarket cable or hand made cable, verify color code before using!
- If you are powering the RTrak-Lite via the 2.1mm coaxial power jack, the only required pins of the radio port are: 1, 3, 5 and 6.